

KATOOL 4 POST LIFT CYLINDER RETRACTED FROM FACTORY

****ALL 4 POST LIFTS SHIP WITH THE CYLINDER RAM RETRACTED TO PREVENT RUSTING DURING OVERSEAS SHIPMENT****

**** It is important to note that the cylinder is designed to be retracted with hydraulic pressure. If the ram is retracted and hydraulic pressure is applied to the cylinder this will cause the cylinder to fail and the warranty to be void ****

****Cylinder ram needs to be extended fully to run each cable to columns****

Please see the following steps

- With lift columns and crossbeams installed, raise the platform to the 2nd or 3rd set of locks.
- Lay underneath the platform making sure there are jack stands placed on either end of the lift to ensure the platform does not fall.
- Place your foot on the lower cylinder bracket.
- Push cylinder ram and bracket upward toward the opposite end of the lift.
- It will be tough to move at first. Once the ram moves slightly it should easily extend out.
- Please see the photo for reference.

